












BOSCH - 0123510034

ALT10550

		
<p>WRT69733 ALT ROTOR</p>	<p>WST87739 STATOR</p>	<p>RTF39797 RECTIFIER</p>
		
<p>BOS1125825521 Bosch DE Bracket</p>	<p>NSK6303M NSK Bearing</p>	<p>BRG62032RS BEARING</p>
		
<p>VRG46402 REGULATOR</p>	<p>SLR39121 SLIP RING</p>	<p>ABR5089 ALT BRUSH SET</p>



BOSCH - 0123510034

ALT10550

A circular black plastic cover with a white slatted pattern in the center. The slats are arranged in a semi-circular, fan-like shape. There are some small holes and a circular opening on the left side.		
EC47111 Bosch Plastic Cover		