



# LUCAS - 23570A

|   |   |   |
|---|---|---|
|    |    |    |
| <b>WRT6558</b><br>Alternator Rotor  | <b>WST8558</b><br>STATOR (Alt. for 8559)  | <b>RTF3950</b><br>RECTIFIER   |
|   |   |   |
| <b>BRG63022RS</b><br>BEARING  | <b>BKT4052</b><br>BRACKET   | <b>NSK6202M</b><br>NSK Bearing  |
|  |  |  |
| <b>VRG3692</b><br>REGULATOR   | <b>SLR3922</b><br>SLIP RING   | <b>ABR5406</b><br>ALT BRUSH SET   |



# LUCAS - 23570A

|  |  |   |
|--|--|---|
|   |   |  |
| <p>BHD3924<br/>BRUSH HOLDER</p>  | <p>EC3925<br/>ALT COVER</p>  | <p>EC4050<br/>ACR PULLEY</p>  |
|  |  |   |
| <p>EC3927<br/>BEARING KIT</p>  | <p>EC3940<br/>ACR ALT CONN SOCKETS</p>   |   |