



LUCAS - 23591A/E

| | | |
|---|---|---|
|  |  |  |
| WRT6558 Alternator Rotor | WST8558 STATOR (Alt. for 8559) | RTF3923 RECTIFIER |
|  |  |  |
| BRG63022RS BEARING | BKT4052 BRACKET | NSK6202M NSK Bearing |
|  |  |  |
| VRG3692 REGULATOR | SLR3922 SLIP RING | ABR5406 ALT BRUSH SET |



LUCAS - 23591A/E

| | | |
|---|--|--|
|  |  |  |
| <p>BHD3924 BRUSH HOLDER</p> | <p>EC3925 ALT COVER</p> | <p>EC4050 ACR PULLEY</p> |
|  |  |  |
| <p>EC3927 BEARING KIT</p> | <p>EC3940 ACR ALT CONN SOCKETS</p> | <p>KIT0001 ALT.REPAIR KIT</p> |
|  | | |
| <p>EC3940 ACR ALT CONN SOCKETS</p> | | |