





# LUCAS - 23819A/B

		
<b>WRT6558</b> Alternator Rotor	<b>WST8558</b> STATOR (Alt. for 8559)	<b>RTF3923</b> RECTIFIER
		
<b>BRG63022RS</b> BEARING	<b>BKT4052</b> BRACKET	<b>NSK6202M</b> NSK Bearing
		
<b>VRG3697</b> REGULATOR (Alt. for 3689/3698)	<b>SLR3922</b> SLIP RING	<b>ABR5406</b> ALT BRUSH SET



# LUCAS - 23819A/B

		
<p>BHD3924 BRUSH HOLDER</p>	<p>EC3925 ALT COVER</p>	<p>EC4050 ACR PULLEY</p>
		
<p>EC3927 BEARING KIT</p>	<p>EC3940 ACR ALT CONN SOCKETS</p>	<p>KIT0001 ALT.REPAIR KIT</p>
		
<p>EC3940 ACR ALT CONN SOCKETS</p>		