












LUCAS - 23944A

		
WRT6558 Alternator Rotor	WST8558 STATOR (Alt. for 8559)	RTF3923 RECTIFIER
		
BRG62022RS BEARING	BKT4052 BRACKET	NSK6202M NSK Bearing
		
VRG3692 REGULATOR	SLR3922 SLIP RING	ABR5406 ALT BRUSH SET



LUCAS - 23944A

		
<p>BHD3924 BRUSH HOLDER</p>	<p>EC3925 ALT COVER</p>	<p>EC4050 ACR PULLEY</p>
		
<p>EC3926 BEARING KIT</p>	<p>EC3940 ACR ALT CONN SOCKETS</p>	<p>KIT0001 ALT.REPAIR KIT</p>
		
<p>EC3940 ACR ALT CONN SOCKETS</p>		